

INSTRUCTIONS FOR STORING WOODBERRY OUTDOOR FURNITURE

All Woodberry outdoor furniture products are designed to withstand being left outside all year round, with the exception of the following products:

- Parasols and Jumbrellas

You should always put parasols down at night and at any time when it is windy. Furthermore, you should use the weather cover provided when the parasols are kept down for 2-3 days or more; this will protect and enhance the life of your parasol or Jumbrella. During prolonged periods of excessively cold or wet weather, you should store your parasols under cover in a cool dry place. Do not store your parasol or Jumbrella in warm or damp conditions as this could lead to growth of mould and mildew.

- Cushions

Whilst Woodberry employs up-to-date technology to ensure that our cushions are water-repellent, Woodberry's cushions are not waterproof. This means that if they are subject to prolonged wet conditions (more than just a light shower) then they should be allowed to dry out in a warm environment overnight. You should store cushions under cover in a cool dry place during prolonged periods of excessively cold or wet weather; this will protect and enhance the life of your cushions. Do not store your cushions in warm, damp conditions as this could lead to growth of mould and mildew.

If you choose to provide additional storage in terms of a weather cover, then this will reduce natural fade and enhance the life of

your outdoor furniture, although this is not strictly necessary.

If you choose to bring any outdoor furniture inside or under cover for a prolonged period of more than 2-3 days, then you should store the furniture in a cool and well-ventilated area. Keeping outdoor furniture in warm or damp conditions could

lead to growth of mould and mildew.

- Bierkeller Tables and Benches

Bierkeller sets are great for covered event spaces but not designed to remain wet or be left outside for prolonged periods.

INSTRUCTIONS FOR USING WOODBERRY FURNITURE AND GUIDANCE ON "EXCESSIVE MISUSE"

All Woodberry outdoor furniture products are designed to withstand normal, reasonable social activity and the furniture products should not be subjected to excessive misuse. Examples of activities which Woodberry considers would amount 'excessive misuse' include the following:

- Climbing or standing all over the furniture
- Cigarette burns
- Carving or hacking
- Vehicle impact or scuff marks
- Damage due to product being dragged over uneven surfaces